


CSV magnet and target status

Shuo Jia

Charge Symmetry Violation



Jlab HallC Sidis

- SHMS: negative polarity for π^- , positive polarity for π^+
- HMS: electrons

$$R_{meas}^D(x, z) = \frac{4N^{D\pi^-}(x, z) - N^{D\pi^+}(x, z)}{N^{D\pi^+}(x, z) - N^{D\pi^-}(x, z)} \quad (1)$$

$$R_Y = \frac{N^{D\pi^-}(x, z)}{N^{D\pi^+}(x, z)} \quad (2)$$

runs with same hms momentum and same absolute shms momentum belongs to same group.


group	polarity	target	runs
140	neg	LH2	6139,6140,6141
		LD2	6136,6137,6138
		Dummy	6129,6130,6132,6133,6135
	pos	LH2	6188,6189,6190
		LD2	6185,6186,6487
		Dummy	6183,6184

group	polarity	target	runs
440	neg	LH2	
		LD2	7611,7612,7613,7614,7615,7616
		Dummy	7617,7618,7619
	pos	LH2	
		LD2	7646,7647,7648,7649,7650,7651,7652
		Dummy	7654,7655


- "*group_num*" : assigned group number for each group. In order of run number. Group number greater than 420 is spring runs group.
- *neg/pos* : runs with negative/positive shms momentum.
- *D2/H2/Dummy* : runs with different target.

- *EPICS* : Provide control and feed back of the device. eg. Magnet current values are read out once per 30'
- $average_{neg}$: average of this value for all pi- runs
- $ratio : \frac{average_{neg}}{average_{pos}}$


Set



analog readback current



rs232 readback current



pattern: up


ecSDI_HP : SHMS HP raw Hall probe value
ecSHB_HP : SHMS HB raw Hall probe value
ecSHB_HallP : SHMS Hall probes HB(corrected)
ecSQ3_HP : SHMS Q3 raw Hall probe value
ecSQ3_HallP: SHMS Hall probes Q3(corrected)



pattern: down

ecsQ1_HP : SHMS Q1 raw Hall probe value
ecsQ1_HallP : SHMS Hall probes Q1(corrected)
ecsQ2_HP : SHMS Q2 raw Hall probe value
ecsQ2_HallP :SHMS Hall probes Q2(corrected)

There is a pattern going along with z.

SHMS Hall probes HB (corrected)







- $hms_P = -6.358$
 - 230 : 6359-6365, $shms_P = -2.966, z = 0.7$
 - 240 : 6367-6372, $shms_P = -2.541, z = 0.6$
 - 250 : 6373-6377, $shms_P = -2.116, z = 0.5$
 - 260 : 6378-6383, $shms_P = -1.691, z = 0.4$
-
- $hms_P : -5.983$
 - 110 : 6104-6114, $shms_P = -3.229, z = 0.7$
 - 120 : 6115-6121, $shms_P = -2.767, z = 0.6$
 - 130 : 6122-6128, $shms_P = -2.304, z = 0.5$
 - 140 : 6129-6141, $shms_P = -1.842, z = 0.4$

SHMS Q1 Hall probe value corrected

average D2




CSV_pi+_x_Q2_0.35_4.00




Choose all positive and negative polarity runs in run group 140, $Q_2 = 3.898$, $x = 0.45$, $shms_p 1.842$, $hms_p - 5.983$


negative for pi-



positive for pi+



Change coordinate system



Rotate along z for $\pi/2$

Rotate along x for shms angle




$$\vec{p}_{beamline} = (P.gtr.px, P.gtr.py, P.gtr.pz)$$

$$\mathcal{R} = \mathcal{R}_x * \mathcal{R}_z$$

$$\mathcal{R} = \begin{bmatrix} 0 & -1 & 0 \\ \cos(\theta) & 0 & -\sin(\theta) \\ \sin(\theta) & 0 & \cos(\theta) \end{bmatrix}$$


$$\vec{p}_{spectrometer} = \mathcal{R} * \vec{p}_{beamline}$$

negative runs for rungroup 140




positive runs for run group 140


pion momentum x



pion momentum y





pion momentum x y



negative for pi-

pion momentum x y




cut1: 68%, cut2: 95%, cut3: 99.7%


xbj for group 140 pi- runs

for negative run

compare xbj without cut and after cut1




compare xbj after cut3 and cut1




compare pi-pi+ runs xbj for group 140

compare xbj for neg runs and pos runs


no cut




cut1



cut2




cut3




z for group 140 pi- runs

for negative runs

compare z after xq2cut and cut1




compare z after cut3 and cut1




compare pi-pi+ runs z for group 140

compare z for neg runs and pos runs


no cut




cut2



cut1




cut3




negative run for rungroup 440, $Q^2 = 5.5$, $x = 0.65$, $h_{\text{msp}} -4.357$, $sh_{\text{ms}} p -2.928$


pion momentum x






pion momentum y



pion momentum x y





positive runs for run group 440



negative for pi-

pion momentum x y




cut1: 68%, cut2: 95%, cut3: 99.7%


xbj for group 440 pi- runs

for negative run

compare xbj without cut and after cut1




compare xbj after cut3 and cut1




compare pi-pi+ runs xbj for group 440

compare xbj for neg runs and pos runs


no cut




cut1



cut2




cut3




z for group 440 pi- runs

for negative runs

compare z after xq2cut and cut1




compare z after cut3 and cut1




compare pi-pi+ runs z for group 440

compare z for neg runs and pos runs


no cut




cut1




cut2



cut3







- *pressure1* : hcD2_P_Exhaust_R, pressure loop D2 return
- *pressure2* : pressure loop D2 before, around 26 psia
- *temperature1, 2, 3* : Temperature at different position
- *density* : read from NIST Chemistry WebBook

D2 status


D2 Pressure pi-



D2 Temperature pi-



An example for LD2 density, this plot is density for D2 at temperature 22.33K, for different pressure(psia).




NIST

National Institute of
Standards and Technology
U.S. Department of Commerce

NIST Chemistry WebBook, SRD 69


black dot for pi- runs, red dots for pi+ runs.

D2 density pi-




H2 status


H2 Pressure pi-



H2 Temperature pi-




H2 density pi-



Back Up


```
{ "6009":1, "6010":2, "6012":3, "6013":4, "6015":5, "6017":6, "6018":7, "6027":8, "6038":9, "6049":10, "6104":11, "6115":12, "6122":13, "6129":14, "6192":15, "6197":16, "6202":17, "6213":18, "6285":19, "6292":20, "6300":21, "6334":22, "6359":23, "6367":24, "6373":25, "6378":26, "6419":27, "6427":28, "6434":29, "6441":30, "6482":31, "6486":32, "6488":33, "6490":34, "6495":35, "6518":36, "6527":37, "6537":38, "6538":39, "6542":40, "6553":41, "7593":42, "7605":43, "7611":44, "7620":45, "7671":46, "7675":47, "7684":48, "7723":49, "7726":50, "7737":51, "7750":52, "7793":53, "7798":54, "7803":55, "7822":56, "7826":57, "7829":58 }
```

CSV_pi-_x_Q2_0.35_4.00



CSV kinematics pi+

- CSV_pi-_x_Q2_0.35_4.00
- CSV_pi-_x_Q2_0.40_4.00
- CSV_pi-_x_Q2_0.40_5.50
- CSV_pi-_x_Q2_0.45_3.89
- CSV_pi-_x_Q2_0.45_4.75
- CSV_pi-_x_Q2_0.50_3.97
- CSV_pi-_x_Q2_0.50_5.00
- CSV_pi-_x_Q2_0.50_5.50
- CSV_pi-_x_Q2_0.55_4.76
- CSV_pi-_x_Q2_0.55_5.50
- CSV_pi-_x_Q2_0.60_4.77
- CSV_pi-_x_Q2_0.60_5.50
- CSV_pi-_x_Q2_0.65_5.50



pion momentum xy

